

the t.amp

TA-50

mini power amp module

th•mann
MUSIC IS OUR PASSION

user manual

Musikhaus Thomann
Thomann GmbH
Hans-Thomann-Straße 1
96138 Burgebrach
Germany
Telephone: +49 (0) 9546 9223-0
E-mail: info@thomann.de
Internet: www.thomann.de

13.08.2015, ID: 328775

Table of contents

1 General information **4**
1.1 Further information 5
1.2 Notational conventions 6
1.3 Symbols and signal words 6
2 Safety instructions **8**
3 Features **12**
4 Installation and starting up **13**
5 Connections and operating elements **14**
6 Technical specifications **17**
7 Plug and connection assignment **18**
8 Cleaning **21**
9 Protecting the environment **22**

1 General information

This manual contains important instructions for the safe operation of the unit. Read and follow the safety instructions and all other instructions. Keep the manual for future reference. Make sure that it is available to all those using the device. If you sell the unit please make sure that the buyer also receives this manual.

Our products are subject to a process of continuous development. Thus, they are subject to change.

1.1 Further information

On our website (*www.thomann.de)* you will find lots of further information and details on the following points:

Download	This manual is also available as PDF file for you to download.
Keyword search	Use the search function in the electronic version to find the topics of interest for you quickly.
Online guides	Our online guides provide detailed information on technical basics and terms.
Personal consultation	For personal consultation please contact our technical hotline.
Service	If you have any problems with the device the customer service will gladly assist you.

1.2 Notational conventions

This manual uses the following notational conventions:

Letterings

The letterings for connectors and controls are marked by square brackets and italics.

Examples: *[VOLUME]* control, *[Mono]* button.

1.3 Symbols and signal words

In this section you will find an overview of the meaning of symbols and signal words that are used in this manual.

Signal word	Meaning
DANGER!	This combination of symbol and signal word indicates an immediate dangerous situation that will result in death or serious injury if it is not avoided.
CAUTION!	This combination of symbol and signal word indicates a possible dangerous situation that can result in minor injury if it is not avoided.
NOTICE!	This combination of symbol and signal word indicates a possible dangerous situation that can result in material and environmental damage if it is not avoided.

Warning signs	Type of danger
	Warning – danger zone.

2 Safety instructions

Intended use

This device amplifies electric audio frequency signals to operate passive speakers. Use the device only as described in this user manual. Any other use or use under other operating conditions is considered to be improper and may result in personal injury or property damage. No liability will be assumed for damages resulting from improper use.

This device may be used only by persons with sufficient physical, sensorial, and intellectual abilities and having corresponding knowledge and experience. Other persons may use this device only if they are supervised or instructed by a person who is responsible for their safety.

Safety

DANGER!

Danger for children

Ensure that plastic bags, packaging, etc. are disposed of properly and are not within reach of babies and young children. Choking hazard!

Ensure that children do not detach any small parts (e.g. knobs or the like) from the unit. They could swallow the pieces and choke!

Never let children unattended use electrical devices.

CAUTION!

Possible hearing damage

The device can produce volume levels that may cause temporary or permanent hearing impairment. Over an extended period of time, even levels that seem to be uncritical can cause hearing damage.

Decrease the volume level immediately if you experience ringing in your ears or hearing impairment. If this is not possible, keep a greater distance or use sufficient ear protectors.

NOTICE!

Risk of fire

Do not cover the device nor any ventilation slots. Do not place the device near any direct heat source. Keep the device away from naked flames.

NOTICE!

Operating conditions

This device has been designed for indoor use only. To prevent damage, never expose the device to any liquid or moisture. Avoid direct sunlight, heavy dirt, and strong vibrations.

NOTICE!

Magnetic fields

The device generates strong magnetic fields that can interfere with the function of poorly shielded devices. The strongest magnetic fields are directly above and below the power amplifier. Therefore, never place sensitive devices such as pre-amplifiers, radio transmission systems, or tape decks directly above or below the power amplifier. When installing the power amplifier into a rack, you should place it in the lowest position, and further equipment such as pre-amplifiers in the highest position.

NOTICE!

External power supply

The device is powered by an external power supply. Before connecting the external power supply, ensure that the input voltage (AC outlet) matches the voltage rating of the device and that the AC outlet is protected by a residual current circuit breaker. Failure to do so could result in damage to the device and possibly the user.

Unplug the external power supply before electrical storms occur and when the device is unused for long periods of time to reduce the risk of electric shock or fire.

3 Features

- Minimal space requirement
- Ideal for mounting on flat panel displays, in suspended ceilings,…
- Output power: 2 × 17 W @ 4 Ω (2 × 20 W max.)
- Integrated limiter
- Suitable DC 24 V power supply included
- Standby feature

4 Installation and starting up

Unpack and carefully check that there is no transportation damage before using the unit. Keep the equipment packaging. To fully protect the device against vibration, dust and moisture during transportation or storage use the original packaging or your own packaging material suitable for transport or storage, respectively.

Establish all connections as long as the unit is switched off. Use the shortest possible high-quality cables for all connections.

The device is suited for mounting on flat panel displays, in suspended ceilings etc. Two suitable mounting brackets are included.

5 Connections and operating elements



1	*[STEREO | BRIDGE]* Switch for operating modes 'STEREO' (channels operate independently of each other) and 'BRIDGED' (channels are interconnected to form one channel with double output).
2	*[LIMITER OFF | ON]* On / off switch for the integrated limiter.
3	*[VOLUME]* Volume control.
4	*[POWER]* Power indicator. The Power indicator is lit green during normal operation and changes to red in standby-mode.
5	*[POWER OFF | AUTO | ON]* Position OFF: Unit switched off. Position AUTO: Unit switched on. The unit automatically enters the standby mode when no input signal is present for 15 minutes. Position ON: Unit switched on, standby feature disabled.

6	*[DC 24V IN]* Phoenix terminals to connect the supplied 24 V power adapter for power supply.
7	*[INPUT]* Input socket (3.5 mm mini phone jack) for connecting the signal source.
8	*[SPEAKER OUTPUT]* Phoenix terminals to connect speaker boxes in bridged (one speaker box with 8 Ω) or stereo mode (two speaker boxes with 4 Ω each), see wiring diagram on the unit.

6 Technical specifications

Output power	2 x 20 W @ 4 Ω
Frequency range	35 Hz…50 kHz, -3.5 dB
Input sensitivity	330 mV (17 W, 4 Ω)
Input impedance	10 kΩ
Signal-to-noise ratio	-95 dB (4 Ω, 1 K)
THD	6.5 %
Protection circuit	Limiter
Control indicator	Power
Power consumption at half output power	40 W
Operating supply voltage	DC 24 V ⎓
Dimensions (W × D × H)	145 mm × 95 mm × 45 mm
Weight	0.6 kg

7 Plug and connection assignment

Introduction

This chapter will help you select the right cables and plugs to connect your valuable equipment in such a way that a perfect sound experience is ensured.

Please note these advices, because especially in 'Sound & Light' caution is indicated: Even if a plug fits into the socket, an incorrect connection may result in a destroyed power amp, a short circuit or 'just' in poor transmission quality!

Balanced and unbalanced transmission

Unbalanced transmission is mainly used in semi-professional environment and in hifi use. Instrument cables with two conductors (one core plus shielding) are typical representatives of the unbalanced transmission. One conductor is ground and shielding while the signal is transmitted through the core.

Unbalanced transmission is susceptible to electromagnetic interference, especially at low levels, such as microphone signals and when using long cables.

In a professional environment, therefore, the balanced transmission is preferred, because this enables an undisturbed transmission of signals over long distances. In addition to the conductors 'Ground' and 'Signal', in a balanced transmission a second core is added. This also transfers the signal, but phase-shifted by 180°.

Since the interference affects both cores equally, by subtracting the phase-shifted signals, the interfering signal is completely neutralized. The result is a pure signal without any noise interference.

1/4" TS phone plug (mono, unbalanced)

1	Signal
2	Ground

3.5 mm TRS phone plug (mono, balanced)

1	Signal (in phase, +)
2	Signal (out of phase, –)
3	Ground

Three-pole 1/8" mini phone jack (stereo, unbalanced)

1	Signal (left)
2	Signal (right)
3	Ground, shielding

8 Cleaning

Fan grids

The fan grids of the device must be cleaned on a regular basis to remove dust and dirt. Before cleaning, switch off the device and disconnect AC-powered devices from the mains. Use a lint-free damp cloth for cleaning. Never use solvents or alcohol for cleaning.

9 Protecting the environment

Disposal of the packaging material

For the transport and protective packaging, environmentally friendly materials have been chosen that can be supplied to normal recycling.

Ensure that plastic bags, packaging, etc. are properly disposed of.

Do not just dispose of these materials with your normal household waste, but make sure that they are collected for recycling. Please follow the notes and markings on the packaging.

Disposal of your old device

This product is subject to the European Waste Electrical and Electronic Equipment Directive (WEEE). Do not dispose with your normal household waste.

Dispose of this device through an approved waste disposal firm or through your local waste facility. When discarding the device, comply with the rules and regulations that apply in your country. If in doubt, consult your local waste disposal facility.

Musikhaus Thomann · Hans-Thomann-Straße 1 · 96138 Burgebrach · Germany · www.thomann.de